

Atmega pin	Atmega		Arduino Uno				
1	PC6	PCINT14	Reset				
2	PD0	PCINT16	D0	0		BT	
3	PD1	PCINT17	D1	1		BT	
4	PD2	PCINT18	D2	2	MOT2	In4	
5	PD3	PCINT19	D3	3	US2	EnB	
6	PD4	PCINT20	D4	4	US1	Trig	
11	PD5	PCINT21	D5	5	US1	Echo	
12	PD6	PCINT22	D6	6	LED	EnA	
13	PD7	PCINT23	D7	7	US2	Trig	Tipk
14	PB0	PCINT0	D8	8	MOT1	In1	
15	PB1	PCINT1	D9	9	MOT1	In2	
16	PB2	PCINT2	D10	10	MOT2	In3	
17	PB3	PCINT3	D11	11	US2	Echo	Buzzer
18	PB4	PCINT4	D12	12	SERVO1		
19	PB5	PCINT5	D13	13	SERVO2		PIR
23	PC0	PCINT8	A0	14	TRIM		
24	PC1	PCINT9	A1	15		MQ	
25	PC2	PCINT10	A2	16	S1 Display		
26	PC3	PCINT11	A3	17	S2 Display		
27	PC4	PCINT12	A4	18	SDA Display		
28	PC5	PCINT13	A5	19	SCL Display		
			SCL		SHT20		
			SDA		SHT20		